



e9 Advantage Series Glass Treatment Instructions for Polish Applications

Polish Application Instructions

1. Ensure the surface is clean and dry as well as free from any oily residue. Use isopropyl alcohol to remove residue.
2. Spray 4-6 squirts of the e9 Advantage Glass Treatment onto a clean, lint-free cloth for each 12 x 12 in. square of glass to treat.
3. Use overlapping circular motion with the lint free cloth on the clean glass surface to treat.
4. Repeat steps 2-3 until the whole glass surface is treated.
5. Check the treated area for any streaks or residue and wipe them off.

The treatment is dry to touch after 15 minutes. For best results let the application cure for 24 hours with limited exposure to outside elements. (See optional heat cure instructions for faster cure time)

Recommendations

1. Gloves and safety glasses are recommended when applying this product.
2. When finished treating parts, be sure to tightly close the e9 treatment bottle to prevent evaporation of the treatment. Store the treatment indoors in a dry, room temperature environment.

Disposal Instructions

Send used, expired, or unwanted e9 Advantage Metal Treatment to an approved waste facility. All waste must be handled in accordance with local, state and federal regulations. Do not allow product to reach sewage system or any water course. See SDS for more information.